

DISCLAIMER AND INSTRUCTIONS

DISCLAIMER:

These surfaces allow for the magnet mounting system to bond securely and remove cleanly:

- **Painted walls** (most smooth, painted drywall)
- **Varnished or painted wood**
- **Glass**
- **Tile**
- **Metal**
- **Laminates**
- **Smooth plastic**

Always clean the surface with isopropyl alcohol (not household cleaners) before applying.

✗ Surfaces it Does NOT Work On

These surfaces can cause poor adhesion or damage during removal:


- **Brick or rough cement** (too porous and uneven)
- **Textured walls or textured paint** (reduced contact area)
- **Wallpaper** (risk of tearing it off during removal)
- **Fabric or soft surfaces**
- **Unpainted wood** (may have dust or loose fibers)
- **Wet or humid surfaces** (e.g., in showers)
- **Dusty or dirty surfaces**

CONTENTS IN BOX:

- **MagPrint**
- **Magnet**
- **4 Picture hanging strips**
- **Isopropyl alcohol swab**

INSTRUCTIONS:

1. Wipe the wall clean with isopropyl alcohol and let it dry completely.
2. Separate the 4 strips from each other.
3. Peel off red sticker and stick to the back of the magnet. Make sure the arrows are sticking out slightly enough for you to grip and pointed as illustrated in the picture.
4. Peel off black sticker and stick to your designated area on the wall.



5. Hold the magnet down with pressure against the wall for **30 seconds** making sure all four sides get pressure.
6. Place your MagPrint so that the magnet lines up near the middle of it and **YOU ARE GOOD TO GO!**

If you got more than one MagPrint you can simply remove and swap their positions as you please. When you are removing the MagPrint from the magnet, grip the MagPrint on the sides of the frame and gently pull towards you.

REMOVAL:

When you want to remove the magnet mounting system, simply pull **SLOWLY** and **STRAIGHT** in the direction the arrow is pointing. The material will stretch for about 10cm before releasing cleanly from the wall. Repeat this for each strip. **DO NOT yank or pull aggressively.**

CLEANING AND CARE:

ONLY use a **MICROFIBRE** cloth to gently wipe the MagPrint to remove dust and dirt.

If you have any questions, you can contact us at deon@mmprints.co.za.

Enjoy your MagPrint!